


Anechoic Chamber Room

Microwave chamber room overview

We support Anechoic chamber rooms for RF measurement, which is for mobile terminals, WiFi, Bluetooth, etc. Not only room itself, supporting total solution including Positioner (Turntable), measurement equipment, which is flexible supported for several systems as Solution Partner of Keysight Technologies Inc.

Spec. example

Size : 5400 x 9400 x 4000 mm
 Frequency : 400MHz ~ 110GHz
 Test Range :
 Max. 6000mm QZφ 1000mm



mm-wave chamber room overview

Available for the evaluation of mm-wave collision prevention becoming standard equipment to Vehicle application. Installing Traverse (Rail for mobile) enable to shift the measuring distance flexible as option, and we could support as customization.

Also, we have supported MRT7681, which is radar Target Simulator, for collision prevention development.

Spec. example

Size : 3600 x 8000 x 3600 mm
 Frequency : 700MHz~40GHz
 75GHz~110GHz
 Test range : around 3000mm
 QZφ 500mm

Anechoic performance :

700MHz	-20dB
1GHz	-30dB
3GHz	-40dB
10GHz~90GHz	-45dB
90GHz~110GHz	-40dB

